

# Human Touch **HT-104** Replacing the Foot and Calf Massager

Initiator: MG

Replaces: 12/02/2002

Revision date: 05/28/2003

## **Removal and Replacement of the HT-100 102 110 120 130 Calf Foot Massager**

Purpose: Removal and replacement of the Calf Foot Massager for HT massage chairs. For HT-10-CRP Chairs with Serial Numbers **ABOVE**: 5100481 (Black Leather), 5300097 (Cream Leather), 5500021 (Black Vinyl), 5700097 (Cream Vinyl).





Tools/Parts Required: Pliers (needle nose and locking), Phillips screwdriver, Small Blade screwdriver

### **POWER OFF CHAIR USING ON/OFF SWITCH AND DISCONNECT FROM AC WALL OUTLET**

#### **REMOVAL and Replacement**

1. Remove seat cushion from chair.
2. Raise the Calf Foot Massager into its highest position. Do this by releasing the handle on the Right side of the chair (as you are sitting in the chair). Locate the Gas Shock under the left side of the Calf Foot Massager. Remove the small e-clip with a small screwdriver blade or needle nose pliers. Using a pair of pliers (locking) remove the silver hinge pin. You may need to apply a twisting motion to do this. Support the Calf Foot Massager unit when you remove the pin. Allow the shock to hang free. **FIGURE 2**
3. Locate the two Silver Pivot Pins securing the Footrest/Calf Massager. Each pin is locked into place with a brace secured by a Phillips Head Screw. **FIGURE 3** Remove the screw and bracket from both the left and right sides. Using a pair of locking pliers, remove the hinge pins. **FIGURE 4-5** You may need to apply a twisting motion to do this. Support the weight of the Calf Foot Massager unit when you remove the second pin. Set the unit on the ground. **FIGURE 6**
4. You will need to follow the cable leading from the Calf Foot Massager to the electrical junction box and cut or release the cable ties securing it to the frame. **FIGURE 7**
5. Locate the electrical connector box located underneath the right side of chair. Remove the two screws securing the cover to the box. Disconnect the white connector leading to the Calf Foot Massager. *You will need to depress the locking lever on the connector.* **FIGURE 8-10**
6. You can now remove the entire Calf Foot Massager and cable from the chair.
7. Replacement of the unit is done in reverse order of removal. Use cable ties to re-secure the cable to the frame of the chair.
8. Reconnect electric connector disconnected from step 5 above. Place the connector back in electrical box, ensuring the black covering cable is inside the box, and no wires are exposed outside the box. Reinstall the cover with the two screws.

# Removal and Replacement of the HTT-10-CRP Calf Foot Massager



# Removal and Replacement of the HTT-10-CRP Calf Foot Massager

