



## REPLACING THE CUP HOLDER

To ensure that Human Touch® products are repaired in a manner that is fully consistent with the practices used during the manufacturing process, Human Touch requires that all product repairs are performed using only factory-new parts and in accordance with these product repair instructions.



SERVICE LEVEL: 2

Tools Required: Phillips-head screwdriver.


NOTE: SAVE ALL REMOVED PARTS FOR USE DURING REASSEMBLY

### REMOVING THE CUP HOLDER

1. The cup holder is located on the right-hand side of the chair. Pull gently outward on the front of the cup holder to deploy it (Fig.1).
2. Using a Phillips-head screwdriver, remove the two screws located at the back of the cup holder (Fig.2).
3. Pull the cup holder out of the chair base.




(Fig.1)



(Fig.2)

## INSTALLING THE NEW CUP HOLDER

1. Insert the cup holder into the chair base.
2. Replace the two screws at the back of the cup holder, using a Phillips-head screwdriver (Fig.3).
3. Push gently on the front of the cup holder to retract it into the chair base.

 CAUTION: Do not place any items in or on the cup holder other than a beverage cup. It is not designed to hold heavy objects, such as books.

