

# Remote Control User Guide

## Hale Premier ZG Recliner



---

**Automatic Timer** – This chair has an automatic 15-minute shut-off timer for all functions other than heat, which shuts off after one hour. Press any button to resume using the chair.

---

**HALE** Premier  
**ZG RECLINER**

# Remote Control User Guide


## USING THE DIAL

**Quick press** to toggle between simultaneous back and footrest adjustment mode and footrest only mode.

**Press and hold** to restore the chair to the upright position with the footrest lowered.

**Turn** clockwise to simultaneously recline the chair and raise the footrest; do the same counter-clockwise to incline the chair and lower the footrest.

To adjust the footrest only, press the MODE button, then turn clockwise to raise the footrest; do the same counter-clockwise to lower the footrest.



For more detailed operation instructions, please see the Use and Care Manual.

**HALE** Premier  
**ZG RECLINER**