

# Remote Control User Guide

## Vesta ZG Chair

**ZeroG®:** Press to recline to zero gravity position.



zeroG



restore

**RESTORE:** Press and hold to restore the chair to the upright position with the leg rest lowered.

**RELAX:** Press to recline into a relaxing lounge position, perfect for watching TV or reading your favorite book.



relax



elevate

position

**ELEVATE:** Press to position the chair in a full recline with legs extended and elevated to help boost circulation.

**BACK:** Press and hold to raise or lower the backrest.



back



legs



posture

**LEGS:** Press and hold to raise or lower the leg rest.



memory



**MEMORY:** Press and hold until the four position buttons on top of the remote flash three times (3x) to save the chair's current position.

**HEAT:** Press to turn on heat in the back and seat areas. The heat automatically turns off after 20 minutes.



heat



massage

**MASSAGE:** Press to toggle through the following vibration massage programs:

- Green – Full-body
- Red – Back only
- Purple – Leg rest only

 human touch®

For more detailed operation instructions, please see the Use and Care Manual.