

# Remote Control User Guide

## AcuTouch® HT-9500x

### FRONT

**8 AUTO MASSAGE PROGRAMS** – Eight Auto Massage Programs offer a wide variety of preprogrammed massages, each designed to meet a specific need. See Use and Care Manual for details on each massage program.

**MASSAGE/COMFORT NUMBER** – Choose from 7 settings of fine-tune massage intensity and contour.

**VIBE** – Foot vibration option.

**SEAT** – Massages the glutes and upper thighs.

**RESTORE** – Press to bring the chair back into the upright starting position.

**SESSION TIMER** – Indicates the number of minutes remaining in the current 15-minute program.

**FIVE MASSAGE TECHNIQUES** – Each massage technique button toggles among auto (alternates speeds), high and low speeds.

**BODY POSITION NAVIGATOR** – Use the Body Position Navigator to adjust the chair to a comfortable position.

**STOP/PARK** – Press to immediately stop the massage.



# Remote Control User Guide

## AcuTouch® HT-9500x

### SIDE



For more detailed operation instructions, please see the Use and Care Manual.